Kodak EasyShare M2008 Battery Replacement

How to safely remove the battery from your device for charging or replacement.

Written By: Kyanna




Step 1 — Battery





- Place thumb firmly on battery cover.
- Slide thumb right, the cover should follow and pop up.

Step 2





- Place thumb on orange tab and pull back towards screen.
- The battery should pop up.
- Gently lift battery out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-20 03:47:33 PM.